WINDOW THERMOMETER

Instruction manual

INTRODUCTION:

Congratulations on purchasing this elegant window thermometer which displays the minimum, maximum and the current outdoor temperature. To enjoy the full benefits of this innovative product, please read this operating manual.



FEATURES

- Transparent LCD display
- Displays minimum, maximum and current outdoor temperature
- Automatically reset the minimum temperature every day at 8:00 pm
- Automatically reset the maximum temperature every day at 8:00 am
- Low battery indicator

TO INSTALL AND REPLACE BATTERIES INTO THE THERMOMETER

The thermometer uses 1 x AAA, IEC LR3, 1.5V batteries. To install and replace the batteries, please follow the steps below:



1. Lift up to remove the cover at the back.
2. Insert batteries observing the correct polarity (see marking).
3. Replace compartment cover.

BATTERY CHANGE:

It is recommended to replace the batteries in all units on an annual basis to ensure optimum accuracy of these units.

Please participate in the preservation of the environment. Return used batteries to an authorized depot.

SETTING UP

1. After the batteries have been installed a full LCD segment will be shown.
2. In about five second, the current outdoor temperature will be shown. The thermometer will capture the maximum and minimum temperature measured and display them immediately.
3. Once the thermometer experience a new highest or lowest temperature, it will renew and display the corresponding minimum or maximum temperature.
4. User shall then advance to the time setting mode to enter the current time in the time (see time setting). The thermometer will automatically reset the minimum temperature every day at 8:00 pm; and reset the maximum temperature every day at 8:00 am.

FUNCTION KEYS

There are two function buttons located at the back under the battery cover. They are the + (Plus) key and SET key



+ (Plus) key

- Press and hold to reset both the minimum and maximum temperature value to the current temperature at the same time.
- Press to adjust hour or minute in time setting mode

SET key

- Press and hold to advance to time setting mode

TIME SETTING

User shall set the current time before use so that the thermometer will automatically reset the minimum and maximum temperature every day at 8:00 pm and 8:00 am respectively:

1. With an appropriate tool, press and hold the SET key for about one second, the hour digits will start flashing.



2. Use the + key to set the hour.
3. Press the SET key again to advance to the minute setting. The minute digits will start flashing.
4. Use the + key to set the minute. Press the SET key again to confirm and return the normal display.

RESETTING THE MINIMUM AND MAXIMUM TEMPERATURE

Manual Reset

User may press and hold the **+** key (with an appropriate tool) for about one second to reset both the minimum and maximum temperature to the current temperature at the same time

Automatic Reset

- The thermometer will automatically reset the minimum temperature every day at 8:00 pm and reset the maximum temperature every day at 8:00 am.
- If the thermometer experience a temperature which is out the measuring range, i.e. lower than -29.9 or higher than 70.0 ˚C, then the max and min will be reset to the current temperature once it is back to a temperature in the measuring range.

POSITIONING

This fancy temperature station is ideal to be placed onto windows (outer glass surface) with a double side tape. Therefore you will observe the temperature outside conveniently.



CARE AND MAINTENANCE:

- Extreme temperatures, vibration and shock should be avoided as these may cause damage to the units and give inaccurate forecasts and readings.
- When cleaning the display and casings, use a soft damp cloth only. Do not use solvents or scouring agents as they may mark the LCD and casings.
- Do not submerge the units in water.
- Immediately remove all low powered batteries to avoid leakage and damage. Replace only with new batteries of the recommended type.
- Do not make any repair attempts to the units. Return it to their original point of purchase for repair by a qualified engineer. Opening and tampering with the units may invalidate their guarantee.
- Do not expose the units to extreme and sudden temperature changes, this may lead to rapid changes in forecasts and readings and thereby reduce their accuracy.

SPECIFICATIONS:

Outdoor temp. measuring range	:	-29.9ºC to +70C with 0.1°C Resolution ("OF.L" displayed if working at temp. lower than -30 or higher than 70 °C)
Outdoor temp. checking intervals	:	Every 10 seconds
Power consumption	:	1 x AAA, IEC LR3, 1.5V (alkaline batteries recommended)
Dimensions (L x W x H)	:	66 x 19.2 x 84.2 mm

LIABILITY DISCLAIMER

- The electrical and electronic wastes contain hazardous substances. Disposal of electronic waste in wild country and/or in unauthorized grounds strongly damages the environment.
- Please contact your local or/and regional authorities to retrieve the addresses of legal dumping grounds with selective collection.
- All electronic instruments must from now on be recycled. User shall take an active part in the reuse, recycling and recovery of the electrical and electronic waste.
- The unrestricted disposal of electronic waste may do harm on public health and the quality of environment.
- As stated on the gift box and labeled on the product, reading the "User manual" is highly recommended for the benefit of the user. This product must however not be thrown in general rubbish collection points.
- The manufacturer and supplier cannot accept any responsibility for any incorrect readings and any consequences that occur should an inaccurate reading take place.
- This product is designed for use in the home only as indication of the temperature.
- This product is not to be used for medical purposes or for public information.
- The specifications of this product may change without prior notice.
- This product is not a toy. Keep out of the reach of children.
- No part of this manual may be reproduced without written authorization of the manufacturer.

Caution:

This thermometer contains glass part.
User shall handle it with care during usage.